



DISHWASHER TABLETS

# POWER ESSENTIAL








FOR EVERYDAY CLEAN



Finish Power Essential, your All in 1 solution for your dishes.  
Our powerball supercharges the tablet for everyday clean  
1st time, every time.



 Save water No pre-rinse	 Clean dish	 Shiny glass	 Eco cycle
 1st time tough stain removal	 Glass protect	 Protects silverware	 Protects dish decor

							
	✓	✓	✓	✓	✓	✓	✓
	✓	✓	✓	✓	✓		
	✓	✓	✓	✓			

## DESIGNED FOR

**All Dishwashers**  
Perfect for Office Kitchenettes



## INGREDIENTS

5-<15% oxygen-based bleaching agents, 5-<15% polycarboxylates, <5% non-ionic surfactants, <5% phosphonates. Contains enzymes (Subtilisin, Amylase). Contains perfume.

**DOSAGE** | 1 tab per wash

## INFORMATION

SKU Code	Tabs	Variant
3205612	15	Lemon
3205609	15	Regular
3074466	42	Regular
3204785	50	Regular
3205256	70	Regular
3204783	100	Lemon
3204606	100	Regular

## COMPLETE YOUR DISHWASHING EXPERIENCE

-   
**RINSE AID**  
For drying & spot prevention.
-   
**DEEP CLEANER**  
Hygienically cleans grease & limescale.
-   
**SALT**  
Protection from limescale residue.
-   
**CARE TABS**  
Degreasing & cleaning boost.
-   
**PROTECTOR**  
Protection from glass corrosion.

Causes serious eye irritation. Keep out of reach of children. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: get medical attention. If medical advice is needed, have product container or label at hand. Do not ingest. If product is ingested then seek medical advice.